

Vibration Measurement, Record and Analysis Systems

MRA-06X / MRA-03X

High sensitivity, high resolution vibration measurement with wide variety of recording, analysis and output display function

Main Feature

- Real time vibration recording and FFT analysis are possible by connecting measurement system and PC.
- Outdoor measurement is also possible in addition to indoor measurement thanks to its portability.

High Performance

- Wide frequency range of 0.1Hz~400Hz
- Wide measurement range from 0.1mGal micro-vibration level to 1700gal seismic domain
- Possible to measure two points for XYZ directions at the same time (MRA-06X)

Wide variety of output display function

- Time domain, Spectrum and Tripartite chart
- · Transmissibility, Phase and Coherence
- · Multi-channel simultaneous display

Vibration Measurement and Analysis System MRA-06X / MRA-03X

MRA-06X/MRA-03X vibration measurement and analysis system acquire analog signal via high sensitivity sensor and amplitude circuit, and then convert to digital data for recording, monitoring and analyzing, and output to wide variety of display function. The system consists of OSP-06/OSP-03 low noise multichannel vibration measurement meter and RS-1 FFT analyzer S/W with high performance servo type accelerometers for 6 (MRA-06X) and 3 channels (MRA-03X).

System Configuration

MRA-06X Configuration

FFT Data Logger

Recording/Analysis Software RS1

PC Interface

USB Cable

BNC Box

BNC Cable
Vibration Measurement Meter

OSP-06

Servo Type Accelerometer

MG-102S x 6

Cable

Sensor Cable

Note PC is prepared by customer.

MRA-03X Configuration

FFT Data Logger

Recording/Analysis Software RS1

Vibration Measurement Meter OSP-03

Servo Type Accelerometer MG-102S x 3

Cable

Sensor Cable

Note PC is prepared by customer.

■ MRA-06X system Configuration •



■ MRA-03X system Configuration



* BNC box is embedded inside Vibration Meter OSP-03.

■ Specification of Vibration Meter (OSP-06/OSP-03)

Vibrartion Me	eter	Accelerometer	Velocity	Displacement	Lowpass Filter	Channel Number	Outline Dimension (W x D x H)	Power	Weight
OSP-06	6	Range 0.1~400Hz	Range 0.4~100Hz	Range 0.5~100Hz Unit 60dB= 0.1mm / V	select 50、100、 200、400Hz (-12dB/oct)	10channel (※Option 16CH)	335×275×60mm	AC 100V to 240V DC 4.5 to 12V	4.5kg
OSP-03	3	Unit 60dB=1cm/s² (1Gal)/ V	Unit 60dB= 1mm/s / V			3channel	325×240×44mm	AC 100V to 240V	3.1kg

■ BNC Box (MRA-06X Accessary)


Analog Input	BNC x 10 Channel (Option + 6 Channel)	
Outline Dimension (W x D x H)	307×264×50mm	

■ Servo type accelerometer (MG-102S)

Measurement Range	±17m/s² (Sensitivity axis is horizontal.)
Resolution	1×10⁻⁶(m/s²)/ √Hz
Outline Dimension (W x D x H)	40×40×55.5mm
Weight	190g

Feature of Vibration Meter (OSP)

- Switchable output of acceleration, velocity and displacement (OSP-06)
- ·Selectable 4 stages of lowpass filter
- •Power supply from AC & DC (OSP-06)




Acc. Vel . Disp. simultaneous output by Tripartite Chart

RS1 Monitor

■ Handy type compact body

Suitable to measure two points vibration (e.g. loading equipment and floor vibration) simultaneously by multi-channel capability.


Range select switch




measurement channel is 10CH.


OSP-03

Suitable to measure one point vibration (e.g. loading equipment



- from the front panel BNC connectors (CH4/5/6).
- Digital signals converted from accelerometer analog signals are recorded for analysis and monitoring.






RS1 Manager

- · Group Data Analysis
- •FFT Analysis for every acquired group
- ·Simultaneously Recorded Data Analysis
- •FFT Analysis for any acquired 2 channels of data

Analysis mode select from instant, summation average and peak hold

Data type select from PSD, 1/3 Oct Band and Power Spectrum

■ Analyzing all kinds of waveform data acquired inside RS1 monitor and displaying for various kind of graphs.



Tranfer function, phase and coherence display

Software Specification of MRA-06X / MRA-03X

The application of MRA-06X / MRA-03X consists RS1 Monitor and RS1 Manager. RS1 Monitor includes libraries for real-time monitoring, data acquisition and I/O. RS1 Manager is a set of acquired data visualization and data analysis.

■ Operational environment

OS	Windows®10				
■ RS1 Monitor					
Data Acquisition Set up	Build a folder to keep acquiring data and give a name to files				
	Measurement frequency range (20/50/100/200/500/1000/2000Hz) (Automatic overlap rate change to match frequency range)				
	Name the groups and specify the channels				
	Decide recording mode (manual, timer or specific needs)				
FFT Set up	FFT summation average				
	Select waveform indication (rms value or 0 to peak)				
	① FFT summation average ② Transmissibility / Overlay	3 Logarithmic frequency indication			

⑤ Reset graphs

8 Save data in CSV file or PNG file

■ RS1 Manager

Option

4 Cursor function

Screen data printing

■ INO I Manager					
	FFT analysis for every data group.				
Group Analysis	Display acquired data in waveform and spectrum of the group.				
	Presentation tripartite chart on single or overlay graph.				
Simultaneous Data Acquisition & Analysis	Run FFT analysis by specifying 2 acquired data channels in any group.				
	Analysis mode	Instant, Summation average or Peak hold			
	Frequency range	Configure frequency range			
	Overlap rate	87.5%,75%, 50% or 0%			
Analysis	Data form	PSD (V√Hz) or 1 /3 Oct.			
Conditions	Select of rms or 0 to peak	rms value or 0 to peak			
	Analysis period	Fix start time and performance period			
	Generation speed	High, Medium, Low			
	Linear or logarithmic scale of X axis				
Option	Conceal or display cursor by click the wanted point on the screen				
	Print analyzed data graph and generate PNG file				
	Save data in CSV file				

Caution for safety • Please read the Instruction Manual carefully before use.

This catalogue is for the product as of OCT, 2021. The specification may be modified without notice.



Tokyo Office

Kansai Office

6 Download specified data & save acquired data

2-5-15, Higashi-Kanda, Chiyoda-ku, Tokyo, 101-0031, Japan Tel: (+81) 3 - 6831 - 0011 Fax: (+81) 3 - 6831 - 0008 10-133, Minami-Hatsushima-Cho, Amagasaki City, Hyogo, 660-0833, Japan Tel: (+81) 6 - 6487 - 3931 Fax: (+81) 6 - 6487 - 3947 10-133, Minami-Hatsushima-Cho, Amagasaki City, Hyogo, 660-0833, Japan Tel: (+81) 6 - 6487 - 3939 Fax: (+81) 6 - 6487 - 3947 Head Office (Factory)

